




- 1) To unscrew the vine you must first warm up well because LOCTITE has been applied
- 2) Insert new lock group respecting the order of the pieces (spring and pin) being careful to align throat (A) with screw hole (B)
- 3) Tighten the screw (use a new one) until it stops check its operation - use LOCTITE