



1) To unscrew the vine you must first warm up well because LOCTITE has been applied

2) Insert new lock group respecting the order of the pieces (spring and pin) being careful to align throat (A) with screw hole (B)

3) Tighten the screw (use a new one) until it stops check its operation - use LOCTITE